Home Security and Smoke Detectors

Our home is equipped with a Honeywell security system with door sensors on all exterior doors and glass break sensors. Our home is located in a very safe and secluded area but if you feel inclined follow the instructions below to arm and disarm the system. There are keypads in the master and inside near the garage door.

To arm the system, simply press the ARM button. The controller will start an exit countdown timer allowing you to leave without triggering the alarm. After the countdown ends, the system will be armed. Opening a door will trigger an event and you will have 30 seconds to disarm the system before the alarms sound.

To Disarm, simply enter the code provided and press the off button. If an alarm event is triggered and the alarms do sound, stay calm. Enter the code and press off to silence the alarm. Enter your code and off a second time to reset the trigger event and put the system back into the "ready" state.

Smoke detectors

The homes smoke detectors are connected to the homes security system. If you accidentally trigger a smoke alarm event, simply go to a control panel, open the cover to access the keypad and press the off button.